Magic Showerhead

How to install your new MagicShowerhead:

1. Remove your old showerhead.



2. Handheld shower head: Replace the old rubber seal ring with the new one. The new seal ring comes together with your new showerhead in the plastic bag.
   Fixed shower head: The new seal ring is already installed in the shower head.
3. Install your new MagicShowerhead. Hands tighten only; usually no need to use a wrench. When you use a wrench, avoid scratching the finish of the shower head by using a soft cloth between the wrench and the shower head.
4. This MagicShowerhead has a water flow regulator. It is integrated inside the showerhead to reach a max water consumption.
5. This reduced water flow will have an impact to the brightness of the LED.
6. Max. water temperature 165° F / 70° C
7. Avoid direct eye contact with the LED.
8. This showerhead is not a toy. Please do not let kids under age of 12 uses this showerhead unattended.
9. Clean regularly the filter at the end of the showerhead.
10. It's recommended to clean the removable transparent cover under running water from time to time.
11. The LED brightness is subject to the water pressure. Maximum water pressure 80psi.

Advice for SH2040/SH1040:
The color of the LED changing by water temperature: Cold=White, Warm=Blue, Warmer=Purple and Red=Hot
You might not see the red LED, if the water is not hot enough. It is not a malfunction when the color is changing between two colors continuously. It is an indication that the water temperature falls between those two colors. Adjust the water temperature until only one color lights up.
WARNING: The Model SH1040/SH2040 with temperature indication will not protect you against getting burned by hot water. The LED light gives you just an indication of the water temperature. Memowell Corp. will not accept any liability for occurrences where the showerhead is used as a safety or precautionary device.